



63620 CLAMP



Code	Model
63620-10	DC-1


63630 ZERO SET

- Fits all dovetail equipped indicators
- Checks the alignment of the centers of round materials
- Equipped with a spindle post with 1/4" , 3/8" and 1/2" dia.




Code	Model
63630	TFH

63640 INDI-GRIP HOLDER FOR DOVETAIL 5/32" STEM TEST INDICATORS



Code	Model
63640	HDI

63646 MECHANICAL UNIVERSAL STAND



Code	Model
63646	WCE-CC8

63625 UNIVERSAL HOLDER FOR TEST INDICATOR

- Suitable for all popular indicators with 5/32" shake or dovetail
- Clamping dia. 1-7/8"
- Reach from 0-12" dia.



Code	Model
63625-10	UIH


63635 COMBINATION AXIAL SUPPORT BRACKET

- Used for mounting indicators on dovetails or rods
- Hinges allow accurate position
- Diameter stem: 3/8"
- Overall length: 5-1/2"




Code	Model
63635	CASB

63645 MECHANICAL UNIVERSAL STAND FOR LEVER DIAL GAUGES



Code	Model
63645	WCE-HP8

63647 MECHANICAL UNIVERSAL STAND



Code	Model
63647	WCE-CA